



**Affordable Reliable Service**

ABN 27 106 103 315

[www.aggdoors.com.au](http://www.aggdoors.com.au)

[enquiries@aggdoors.com.au](mailto:enquiries@aggdoors.com.au)

(03) 8789 1342



*Genuine TB6*

## **Coding your Remote into the Opener**

- Press the CODE SET button from the motor and release. The CODE SET LED will illuminate to indicate the opener is in Code Learn mode. If a valid code is not stored within 15 seconds the opener will exit Code Learn.
- Press the remote button that you want to open / close the door. The CODE SET LED will begin to flash.
- Press the same remote button again. The CODE SET LED will illuminate for one second and then go out.
- The remote is now coded to operate the door – press the button to test.

## **Deleting the Codes**

If the CODE SET button is pressed and held for 6 seconds the CODE SET LED will blink rapidly for one second to indicate that all codes have been erased.

